

Bulb Changer

6-Piece Accessory Kit

Model BCL06-1 **User Guide**

What's Included









Bulb Changer with 14ft String


Press-Fit Suction Cup Locking Pin (Recessed Lights)



Large Spring-Cage (Flood Lights)








Candelabra Extractor




Mesh Storage Bag with Drawstring



Assembly

Attaching Accessories


Position the accessory where ${\color{black} both}$ holes align to create a clear path.





- STANDARD-SIZE spring-loaded cage for incandescent light bulbs:
- · Push cage on from the bottom onto standard light bulb.
- Turn to the left (counterclockwise) to loosen and remove light bulb.

While keeping the holes aligned, insert accessory into the top of the bulb changer.





LARGE-SIZE spring-loaded cage for flood light bulbs: Slide attachment onto flood light bulb by pushing it over

the bulb from the side. Turn to the left (counterclockwise) to loosen and remove light bulb.




Insert locking pin into the bulb changer (twist pin as you insert into hole).





Assembly Attaching An Extension Pole*




Instructions

- Always shut off electrical power to the bulb you are changing! Allow time for bulb to cool.
- Select the appropriate attachment and Insert locking pin to secure (Assembly Step #3).
- Screw onto the threaded end of an extension pole (not included). Hand tighten the thumb-screw on the EZ Smart bulb changer secure pole.

Press button to turn on LED light if needed.



Broken-bulb Removal



Standard Extracto



INSTRUCTIONS: Turn off electricity before changing bulbs. Wear hand and eye protection when handling broken glass.

- Choose 1/2" candelabra or standard 1" extractor to fit the bulb base.
- To remove broken bulb gently push up and twist counter-clockwise, increasing pressure as needed.

🛕 CAUTION: DO NOT USE PLIERS OR OVER TIGHTEN THE THUMB SCREW

Removing Attachments

- Hold the bulb changer base securely in one hand while pressing firmly on one end of the locking pin. With your other hand pull the opposite end of locking pin.
- Continue pulling until the pin is fully removed, allowing you to replace it with a different attachment.






Suction Cup Attachment

- For bulb REMOVAL center suction cup on flat/smooth bulb and press gently to create suction.
- Once secure, turn bulb changer counter-clockwise to unscrew.

Lower and remove bulb from suction cup pulling draw string to release suction.



- For BULB REPLACEMENT, center the suction cup on the new flat, 1 smooth bulb and press gently to create suction.
 - Using an Extension Pole (Optional): Align the threads of an extension pole (not included) with the socket on the EZ Smart bulb changer. Turn the pole clockwise to secure it into place. Then, tighten the thumb screw on the EZ Smart bulb changer to ensure the pole is secure.
- Activating the LED Light: Unwind the string and press the button on the LED light attachment to activate illumination.
- Bulb Installation: Stand directly beneath the light bulb socket (not at an angle). Guide the new bulb into the recessed light housing. Turn the bulb changer clockwise (right) until the bulb is fully threaded into place.
- Releasing the Suction: Pull the string to release the suction from the bulb, then carefully lower the EZ Smart bulb changer. Press the button on the bulb changer to turn off the LED light.
 - TIP: Bulbs that have been too tightly installed may require removal by hand. Using EZ Smart Bulb Changer for replacement will ensure easy operation in the future.

SCAN FOR MORE INFO





MARNING: This product can expose you to chemicals including Lead, which is known to the State of California to cause reproductive harm. For more information go to www.P65Warnings.ca.gov

MADE IN CHINA Distributed by EZ Smart Co. Omaha, NE